

# CORNUFÉ SERIES CLEANING TIPS

LA CORNUÉ

CORNUFÉ

## CLEANING SUPPLIES

### NAME BRAND CLEANING SUPPLIES:

Windex Cleaner®

Bon Ami®

Barkeepers Friend®

Weiman Stainless Steel Disposable Wipes®

*The following brand name products are available online:*

Dawn Power Dissolver®

<https://www.pjmarketplace.com/dawn-power-dissolver-6-pack-32oz.html>

**PLEASE NOTE:** This product can only be purchased online at [pjmarketplace.com](https://www.pjmarketplace.com)

Scotch-Brite®

3M 07447 Scotch-Brite® Maroon General Purpose Hand Pad, 20 Pack

<https://tcpglobal.com/products/mmm-7447>

**PLEASE NOTE:** This product can be purchased online at [tcpglobal.com](https://tcpglobal.com)

*Option to be used with hand pad above:*

Twist-Lok Pad Holder in Gray by Magellan Distribution Corporation

[https://www.amazon.com/dp/B000JKAIVW/ref=cm\\_sw\\_em\\_r\\_mt\\_dp\\_U\\_\\_c2ReCbYC8DB6V](https://www.amazon.com/dp/B000JKAIVW/ref=cm_sw_em_r_mt_dp_U__c2ReCbYC8DB6V)

**PLEASE NOTE:** This product can be purchased online at [amazon.com](https://www.amazon.com)

MAAS® Metal Polish

[https://www.amazon.com/dp/B0008D7IV8/ref=cm\\_sw\\_em\\_r\\_mt\\_dp\\_U\\_\\_opSeCb50K9EYK](https://www.amazon.com/dp/B0008D7IV8/ref=cm_sw_em_r_mt_dp_U__opSeCb50K9EYK)

**PLEASE NOTE:** This product can be purchased online at [amazon.com](https://www.amazon.com)

### GENERAL CLEANING SUPPLIES:

Microfiber Cloths

Non-Abrasive Sponge

Paper Towels

White Vinegar

Mild Dish Soap

Rubber Cleaning Gloves [Use with Dawn Power Dissolver®]



## PANEL CLEANING:

### **POLISHED ENAMEL PANELS (ALL COLORS EXCEPT MATTE FINISHES):**

Apply warm and mild soapy water to a microfiber cloth and agitate to remove grease or food stains. Promptly dry area with a clean microfiber cloth. Windex® can be used as an alternative to optimize shine when applied to a clean microfiber cloth first. Never spray Windex® (or any cleaner) directly onto enameled surfaces.

### **MATTE ENAMEL PANELS:**

Apply warm and mild soapy water to a microfiber cloth and gently agitate to remove grease or food stains. Promptly dry area with a clean microfiber cloth.

### **BRUSHED STAINLESS STEEL:**

Stainless Steel may darken over time. To restore luster, clean with Stainless Steel Wipes; we recommend Weiman Stainless Steel Disposable Wipes®. Use a clean microfiber cloth to remove any remaining residue.

## ACCENTS:

### **POLISHED BRASS:**

Be sure to have a good supply of clean microfiber cloths on hand. Brass trim on CornuFé ranges are not lacquered and will patina naturally. Patina can be removed with brass polish; we recommend MAAS® Metal Polish. Follow manufacturer instructions provided with product. Apply polish to clean microfiber cloth and coat a small area. Do not allow polish to dry or remain on surface for extended periods of time. Use a clean microfiber cloth to remove any remaining residue.

### **CHROME:**

Polished Chrome and Polished Stainless Steel are low-maintenance and require little polishing, if any. As needed, clean with Windex® or Weiman® Stainless Steel Wipes. Use a clean microfiber cloth to remove any remaining residue.



## COOKTOP:

### BURNERS GRATES:

Apply warm and mild soapy water to a microfiber cloth and agitate to remove grease or food stains. Promptly dry area with a clean microfiber cloth. Dawn Power Dissolver® can be used for stubborn areas.

### GAS BURNER CAPS:

To remove burnt on grease, wash with warm soapy water. Make sure that all holes around the cap are free of grease and food debris.

*\*Allow enough time for the piece to cool before handling. Rinse and dry. To obtain a shine, use MAAS® metal Polish with a dry microfiber cloth.*

### STAINLESS STEEL COOKTOP:

Scratches may appear over time. Using a maroon Scotch-Brite® pad (holder recommended) **gently rub parallel to grain**. Use a **stainless steel wipe** to remove any residue from pad.



## O V E N S :

Use a sponge and warm soapy water to remove any splatters of food or grease. The oven may be warmed slightly before cleaning to soften baked-on foods and grease. For baked on grease be sure to use Dawn Power Dissolver®. (Spray and let it sit for about ten to fifteen minutes.) Use a damp clean microfiber cloth to remove. Never use any abrasive cleaner (such as Comet®) as these products may compromise the enamel seal. Dawn Power Dissolver® can also be used on oven accessories such as oven racks, roasting dish, and trays. Be sure to rinse thoroughly.

