





ASSEMBLY INSTRUCTIONS

1. HANDRAIL INSTALLATION



You have the option of installing the handrail as shown or adding the small plastic tabs inside the support to prevent the bar from rotating.




Place a rotating block at each junction of the bar and push the end piece before mounting the concerned tube.

2. RISER / BACKSPLASH INSTALLATION



8 mm




3. HEIGHT ADJUSTMENT

Château cookers are equipped with adjustable legs so the height of the cooktop can vary from 912 mm (35.90 in) to 928 mm (36.53 in).

Remove the drawers and plinthes/toe-kicks, set the cooker in place, screw up the central legs so the cooker rests on the outside legs and adjust the height.

Once the cooker is resting at the right height and is level, screw down the central legs to balance the weight.



Install the plinthes/toe-kicks using a standard screwdriver.

Use the Standard T-20 Screwdriver to Install the Plinthes/Toe-Kicks to the Range.



4. GAS CHIMNEY PROTECTION INSTALLATION

Gas chimney protection plate comes separately in the package and needs to be installed above the flue channel behind the gas oven.

